# How to phone guide

### Place an Internal Call

- 1. Lift handset.
- 2. Dial 4 digit extension number.

### Place an External Call

- 1. Lift handset.
- 2. Dial 9 + number may be prompted for Authorization Code for long distance calls.
  - a. You will hear ringing if call is allowed.
  - b. You will hear a dial tone if call is restricted.

### Three-Way Conference Calls

- 1. During initial call, press FLASH.
- 2. Dial 4 digit extension number for internal call or 9 plus the number for an external call.
- 3. Once answered press FLASH to connect conference.

## **Transferring Calls**

- 1. During initial call, press TRANSFER.
- 2. Enter the extension to transfer the call to.
- 3. Hang up the phone.

### Call Hold

- 1. Press HOLD button
- 2. To reconnect: press the flashing line key.

**Call Park** (Use this feature to put someone on hold and move to a different phone)

- 1. During initial call press the PARK button.
- 2. Dial your own 4 digit extension number.
- 3. Hang up
- 4. Go to the other phone and lift the handset.
- 5. Press PARK + your own 4 digit extension number.
- 6. You are now connected to the caller.

**Camp-On** (If you receive a busy signal on an internal call, use this feature to be connected when they hang up)

If you receive a busy signal on an internal call:

- 1. Press CAMP-ON button.
- 2. CAMP-ON lamp goes on.

When the party you are trying to reach hangs up:

- 1. Your telephone will ring.
- 2. The other person's telephone will ring.
- 3. Connection will be made.
- 4. CAMP-ON lamp goes off.

### **Forward All Calls**

- 1. Lift handset or press SPEAKER button
- 2. Press FORWARD ALL CALLS button
- 3. Dial 4 digit extension or voicemail 7999

### To cancel:

- 1. Lift handset
- 2. Press FORWARD ALL CALLS button.

### Do Not Disturb

1. Press DO NOT DISTURB button to activate and all calls directed to voice mail without ringing phone.

### To cancel:

1. Press the DO NOT DISTURB button again

### Last # Redial

Press LAST # REDIAL button to redial the last number dialed.

# Auto-Dial/Speed-Dial

- 1. Do Not lift the handset.
- 2. Press PROGRAM button.
- 3. Press AUTODIAL button.
- 4. Dial the extension or outside number.
- 5. Press PROGRAM button again.

# **Message Waiting**

The Message Waiting button flashes when you have a new message in your voice mailbox.

- 1. Lift handset
- 2. Press Message Waiting button to retrieve a message left in your Voice Mail box.